

Surge Irrigation

Chris G. Henry
Associate Professor
Water Management Engineer

L. J. Krutz, Ph. D.
Director, Mississippi Water
Resources Research Institute
Mississippi State University

Drew M. Gholson, Ph.D.
Assistant Professor &
Extension Irrigation Specialist
Mississippi State University

What is Surge Irrigation?

Surge irrigation is the intermittent application of water used to improve distribution uniformity along a furrow. It works on the principle that dry soil infiltrates water faster than wet soil.

When soil is wet, it seals because the soil particles at the surface consolidate. When water is re-introduced in a furrow that has been wet, the wetting front moves quickly past the wetting zone to dry soil. At the wetting interface, dry soil slows the advance. This phenomena allows for a faster advance through the field with less deep percolation and better application uniformity resulting in a more even distribution of water in the rooting zone from the poly-tubing to the tail ditch, and reduced nutrient loss from deep percolation near the poly-tubing.

Surge irrigation is performed through a program of cycle times that account for the advance of the furrow. These cycle times must be set by the user.

Some tail water is necessary with surge irrigation for it to be effective. The intermittent application reduces the tail water volume, because the water is moving as a pulse over the sealed furrow to the end of the furrow. The velocity of the water decreases as it moves along the furrow and has more time to infiltrate before it leaves the furrow. When set properly, very little tail water leaves the furrow.

A valve that simply moves from one set to another at a uniform or constant time interval is not surge irrigation.

Definitions

Advance time: Time that is required for wetting front to “advance” from the crown to the end of the furrow.

Recession time: Time for the wave front to recede from the furrow. Essentially this is when the majority of the tail water has stopped draining from the field.

Opportunity time: Time for water to infiltrate into the soil. The more time water is in contact with the soil, the more volume is infiltrated.

Soak Time: Time after advance has completed where the remainder of the set time is used to meet the required application depth.

Application depth: The depth of irrigation applied during a surge irrigation. This depth should be between 2.5 and 3.0 ac-in.

Number of cycles: The number of advance cycles (water on/water off) used to complete a surge advance program. Generally, surge advance times increase during the surge program, although some surge programs have a longer first advance than second advance before increasing.

On-time: The time water is applied to a given side

Off-time: The time water is not applied to a given side

*Arkansas Is
Our Campus*

Visit our website at:
<https://www.uaex.uada.edu>

Cycle-time: The time required to complete an on/off cycle (sum of on-time and off-time)

Irrigation set time: The total irrigation time, which includes advance and soak times. The set time for row crops should always be less than 40 hours. If using a CHS plan, you must add the time for each set together to calculate the irrigation set time. For example, if a surge is being used on two 24 hour sets, the total time is 48 hours and the sets should be divided into three sets.

Computerized Hole Selection for Surge Irrigation

If lay flat irrigation pipe is going to be used with surge irrigation, as is common in mid-south agriculture, then the surge irrigation sets must be planned using Computerized Hole Selection (CHS) such as Delta Plastics' Pipe Planner (www.pipeplanner.com) or PHAUCET (Pipe Hole And Uniform Crown Evaluation Tool). CHS allows for hydraulic iteration of pressure, row length, and elevation so that each furrow receives the proportional amount of water for the row length. It also provides for uniform distribution of irrigation water across the crown of the pipe (along the pipe), thus allowing the surge valve to improve the down furrow uniformity (top to bottom of field distribution uniformity will be improved).

To lay out surge irrigation, two irrigation sets must be combined. For example, if an irrigation set was used to irrigate a 35 acre field or set, then it must be subdivided into two sets of equal size (17.5 acres) or similar size (20 acre and 15 acre). The time to irrigate each set is combined for the total irrigation set time, and **it is recommended not to exceed a total time of 40 hours. Twenty-four hours is preferred.** Ideally, sets should be reduced to 24-30 hour irrigation times (total irrigation set time).

When possible, locate surge valves at risers, valves, or bonnets. It is preferable not to have any lay flat pipe supplying irrigation water to a surge valve due to valve motion. A surge valve can be used for multiple sets in a field — for example, a 40 acre field can be divided into four, 10 acre sets and the valve used for two sets at a time then switched to the other two. Place a short piece of rigid pipe in the valve and secure with poly pipe tape, to ease the process of connecting pipes. Use pipe clamps to secure the lay flat pipe to the valve between surge sets.

Anatomy of a Surge Valve

A surge valve consists of an electronic controller and an aluminum mechanized valve that diverts water from one side to the other. This is referred to

as right and left side. P and R surge valves have advance and soak cycle modes. The valve started out in the advance mode and then moves into the soak mode after the advance time has been reached. It continues indefinitely in the soak mode until it is shut off.

The most critical step is programming the advance time correctly in a surge valve. Once you reach the soak phase in the program you cannot go back to the advance phase. Set the anticipated time of the advance phase just slightly less than the actual advance time observed in the field from an advance. In many cases the time that is normally taken to advance through the field will be about half for a surge irrigation.

Use a CHS plan to plan the surge time. For example, if a CHS plan calls for a 24 hour set time, then expect a 12 hour advance. However, the advance time is highly variable and the user must determine the advance from experience, so the advance should be monitored during the first irrigation until it is known or can be predicted. For example, if a 24 hour set is required to put on 2.5 ac-in application depth, and it is observed that the advance is halfway through the field at nine hours, then adjust the advance time down from 24 to 18 hours.

Below is guidance for setting a surge valve for different soils and conditions. However, there is no hard, fast rule and sometimes the user must experiment with the valve to obtain the best results is necessary.

Sandy Soils

Surge valves are especially useful in sandy soils, as the challenge with coarse textured soils is minimizing deep percolation and getting water through the furrow. Thus set the valve as normal, although expect a longer advance time (it will probably be greater than 50 percent of the irrigation set time). Use default cycle times. Increasing the number of cycles may improve the irrigation.

Silt Loams

Surge valves are useful in silt loam soils, especially those that seal. In silt loams that do not seal and infiltrate well, use same process as sandy soils.

For silt loams that seal, it will likely be necessary to make substantial changes to the program. Often in silt loams that seal, the advance will be much less than expected. For example, for a set time of 24 hours, the advance may be completed in six hours. Adjust the advance time to five hours, increase the number of advance phases by +1 or +2. Operate the valve in soak mode for the remainder of the irrigation set, and reduce the flow rate to increase opportunity time.

Clay soils (cracking)

In cracking soils, the surge valve should be used only in the advance mode. Set the advance time to the total irrigation set time. Do not operate in soak mode. Also reduce the number of advances so that there are only three to four advance cycles. The surge valve works in a clay soil because in the off cycle, the soil cracks seal up and allow the advance to quickly move through the furrow on the next advance. Recommended advance settings are shown in Table 1.

Table 1: Surge Valve Star Controller Recommendations for Clay Soils

Advance Setting	Default Cycles/Side Setting	Custom Cycles/Side Recommendation
Input by user	Under custom tab	Use down arrow to adjust
5	4	4-1 (3) total
10	5	5-2 (3) total
15	6	6-2 (4) total
20	6	6-2 (4) total
30	6	6-2 (4) total

It is recommended that the number of cycles per side equals the default setting, minus two. The total cycles per side should never be less than three.

Unbalanced set sizes

Two sets of different sizes can still be surge irrigated. For example, if one set is 15 acres and another is 20 acres, the valve can be adjusted to increase the advance times for each set. In this example, 43 percent of the time the valve will divert water to the 15 acre set, and 57 percent of the time it will divert water to the 20 acre set. This can be input directly into the valve through a custom menu.

Operation

Surge valves operate on solar power and a battery. The voltage of the battery and solar panel can be

checked through the custom menu (hold button down for three seconds on a P and R). Valve controllers need to be charged and turned off in the off-season. During the season, they need to be shut off after an irrigation event, or else they will continue to move the valve. If left unattended, they will drain the battery.

It is highly recommended to use a circle lock or horseshoe clamp to secure the surge valve to a bonnet or hydrant. The oscillation of the valve can dislodge it from the water source. When starting an irrigation, the valve can be changed from the right or left side by using the change button — it does not advance the program when done during the first advance cycle. The valve pauses before switching completely over. This is a setting that can be changed in most valves if water hammer is occurring from high flow rates.

Use of soil moisture sensors or a soil moisture monitoring unit can be useful in evaluating the effectiveness of a surge irrigation program, and to optimize settings.

In some cases surge can reduce the advance time, in other situations it will increase the advance time. Reducing the advance time will result in a water savings. An increased advance time typically indicates that more water has been applied to the soil, likely indicating that fewer irrigations will be necessary, overall resulting in less total irrigation water needed to meet crop water demand. Thus the benefit of surge irrigation is not always apparent from visual observation alone.

Summary

Surge Irrigation is the intermittent application of water in furrow irrigation for the purpose of improving down furrow efficiency and reducing deep percolation. A programmed automated valve is used with lay flat pipe that has been planned with set sizes. Surge irrigation must be adapted and adjusted to field and soil type conditions. Plan surge irrigation sets for a total irrigation time of 24 hours and use CHS to determine lay flat pipe hole punch plans.

Acknowledgement: This fact sheet is a joint publication with Mississippi State University.

Printed by University of Arkansas Cooperative Extension Service Printing Services.

CHRISOPHER G. HENRY is associate professor and water management engineer at the Rice Research and Extension Center, University of Arkansas System Division of Agriculture. **L. JASON KRUTZ** is director of the Mississippi Water Resources Research Institute at Mississippi State University. **DREW M. GHOLSON** is assistant professor and extension irrigation specialist at Mississippi State University.

Issued in furtherance of Cooperative Extension work, Acts of May 8 and June 30, 1914, in cooperation with the U.S. Department of Agriculture, Director, Cooperative Extension Service, University of Arkansas. The University of Arkansas System Division of Agriculture offers all its Extension and Research programs and services without regard to race, color, sex, gender identity, sexual orientation, national origin, religion, age, disability, marital or veteran status, genetic information, or any other legally protected status, and is an Affirmative Action/Equal Opportunity Employer.